ASSEMBLY INSTRUCTIONS

ITEM CODE : **IN311**

ITEM DESCRIPTION : **CONSOLE TABLE**

1 Reverse the console table & place the leg as shown & align the leg to match the apron.

Insert the Bolt to fix the leg with the console table top and tighten the nut with the washer as shown in fig1

2

3 Fix the other leg pair in the similar way

4 Reverse the console table straight. Now your console table is ready for use.

Fig. 1

Allen key

Screw 2

Screw 1

Washer 2

Washer 1